Fanlink

Ventair — THE AIR MOVEMENT SPECIALISTS

Skyfan DC — The future in fans

Model: FLINKPIX

PIXIE Smart Home App Control Module
(for use with the Ventair SKYFAN)

PIXIE

GET IT ON Google Play

Download on the App Store

PIXIE PLUS

Installation:

1. Isolate power to the fan.
2. Twist fan canopy in a clockwise direction to drop it down.
3. Remove orange dust cover from the USB slot on the SkyFan receiver.
4. Carefully insert the FLINKPIX module.
5. Replace canopy by sliding upwards and re-fix by twisting anticlockwise.

App Selection:

There are two apps: PIXIE and PIXIE PLUS. Both are available for free on your Android or Apple mobile device.

The most suitable app for you will depend on your individual needs.

PIXIE is best used for customers who:
• Do not require out-of-home control.
• Do not require voice control.
• Prefer not to connect their smart home components to the internet.

PIXIE PLUS requires a Wi-Fi connection as well as a **SAL PIXIE GATEWAY (Available Separately)**.
Additional PIXIE PLUS features include: Out of home control, Voice control, Scheduling of Scenes as well as Google Home, Amazon Alexa, Siri & SmartThings support.

Adding your Skyfan DC to the PIXIE App:

• Ensure Bluetooth is enabled on your phone.
• Open the **PIXIE** App and allow any permission requests.
• **PIXIE** will automatically start searching for compatible devices.
• A list of compatible devices will be shown, locate your Skyfan and press "Add".
• Select "Finish" or "Add More" depending on the number of devices being set up.

Adding your SkyFan DC to the "PIXIE PLUS" App:

• Ensure you've created a **PIXIE PLUS** account and setup your **PIXIE GATEWAY.**
• Ensure Bluetooth is enabled on your phone.
• Open the **PIXIE PLUS App**, allow any permission requests & log in.
• Tap "Device" on Home Page the tap " " in the right corner and select "Add device".
• Locate target Fan. Tap the "Add" button, and the fan will be added momentarily.

Canopy Drops Down

Rotate Clockwise to release

Skyfan DC
The future in fans

ventair tm
THE AIR MOVEMENT SPECIALISTS

Fanlink

PIXIE APP Fan with light

Add Fan into the APP

Fan control via PIXIE (Basic)

Adjust Fan speed

Fan ON/OFF

Fan light ON/OFF

Adjust light brightness

Change light color
temperature accordingly

Tap "Device" on Home Page

Tap " ⋮ " from right of corner.
Select "Add device".

Locate the target Fan.
Tap on the"Add" button, then
wait and "Finish" when instructed.

On the device list, tap the bar under
the Fan name to toggle Fan status.
Tap the device name to get into the
detailed device page.

Fan speed and light control
as indicated.

Fan control via PIXIE (Advanced)

Rename the Fan

Rename the Fan Light

Choose to enable
Winter mode

Choose to be excluded
from All Device's Group
control

Tap " ⋮ " from right of corner.
Select "Edit".

Edit Fan information, i.e., name,
switch between summer/winter
modes & various other function.

Tap " ⋮ " from right of corner, select "Timer Off".
Choose the countdown period, tap "Start" to
commence the sleep timer.

On "Timer Off" page, tap "<" from the left top corner
to return to the detailed device page, where the sleep
timer countdown can be seen.

Adding your SkyFan to the PIXIE PLUS APP

Rename device

Create a new room

Assign the device to an existing room

Adjust Fan speed

Fan ON/OFF

Fan light ON/OFF

Adjust light brightness

Change light colour temperature

Fan mode selector

Tap "Device" on Home Page
Tap "⋮" from right of corner.
Select "Add device".

Locate the target Fan.
Tap the "Add" button,
then wait.

Once the device is added, tap on the "✎" icon to rename or assign the newly added fan to a room.

On the Device list, tap the bar under the Fan name to toggle its status.
Alternatively, tap the device name to get into the detailed device page.

Fan speed, light status and colour temperature are shown.

PIXIE PLUS - Changing your fan name and timer functions

Rename the Fan & Fan light

Winter mode toggle

Choose to be excluded from All Devices Control

Tap "⋮" from right of corner.
Select "Edit".

Edit Fan information, i.e., name, summer/winter modes & some other function.

Tap "⋮" from right of corner, select "Timer Off".
Choose the countdown period, tap "Start" to commence the off timer.

On the "Timer Off" page, tap "<" in the top left corner to return to the detailed device page. You will now see the timer progress icon in the top right.